

EZMIMI II

User Manual



ENGLISH3

■ Product Introduction3

■ Specification Chart4

■ Installation Guide6

■ LED Indicator.....7

■ Product Introduction

Product Name/Model	EZMIMI II
Supported Platforms	Windows 7/Vista/Win XP/2000/ME/98/NT4.0/CE; Linux; Mac
Product Descriptions	<ul style="list-style-type: none"> - Complies with PC / SC standard and certified by Microsoft - Complies with ISO7816-1, 2, 3; T = 0 and T = 1 card specification - Card converter, Exclusive patent. -USB Interface(USB2.0 version - full speed), for Laptop - API Library and Software Development Kit - Computers and Internet security control (Access Control), e-Commerce or Royal program - Small and light, especially for business purpose and travelers - For WebATM systems specified by Association of Banks - For MOICA Citizen Digital Certificate -Support Plug in and go -Multiple colors
Certification and Standards	BSMI, FCC, CE, RoHS, EMV Level1, ISO7816, VCCI, UL



■ Specification Chart

Size	68.1mm(L) X 34.6mm(W) X 9.7mm(H)
Weight	Approximately 14 gram
Casing Material	ABS
Extension Cable	USB A Type-MiniB cable; length 50cm
LED Indicator	Reader status is indicated by red and green colors.
Power Supply	USB Port Power
Socket Specification	Read/Write Smart Card and mini SAM /SIM Card (Optional : 1 piece)
Socket Type / Lifespan	Contact Type/ Over 100,000 of inserts
Card Specification	Complies with ISO7816-1,2,3 and T=0, T=1 protocol CPU Card ; Read/Write 4404 、 4418/28 、 4432/42 、 4406/36/5536 and I ² C Memory card
Communication Interfaces	USB Interface - Support USB2.0 (full speed)
Driver	Windows7 32/64 bit . Windows Vista 32/64 bit . Windows XP 32/64 bit . Windows 2000 . Windows ME . Windows 98 . Windows NT 4.0 . Linux . Mac
Driver Standard	CCID, PC/SC WHQL
Development KIT	Provide PC/SC environment API or CT-API for application development
Certification	Complies with CNS, FCC Part15, Euro CE, EMV Level1, ISO7816 Standard
Operating	Operation Temperature 0 °C ~45 °C

Environment	Storage Temperature -35 °C ~70 °C
--------------------	-----------------------------------

■ Installation Guide

Step(1) : Connect EZ MINI II reader to PC via USB port.

Step(2) : Place the installation CD to the CD-Rom then execute "Autorun.exe" on the installation CD.

Step(3) : Select the driver of "EZ MINI II - CCID" under "Reader Model" field.

Step(4) : After installation completes, the "Restart your computer" message will prompt. To complete the installation process, please select "Yes, I want to restart my computer now".

Note : After the computer is restarted, to check if the reader is properly installed, please go to the device manager smart card field.

■ LED Indicator

Yellow/Green : Indicates the power status, on when power is supplied.

Red : Indicates a card has been reset, blinks while reading a IC card.